

Dimensions: Various Sizes Available - See below for details



SIZES AVAILABLE

- ½ " valve
- ¾ " valve
- 1 " valve
- 2 " valve
- 3" available upon request

The float ball Valves are designed to be fitted into our water bowser to allow a water feed to flow into the bowser until they are at capacity.

They will then automatically shut off when the water is at the desired level.

When the water level in the bowser drops it will open again and continue to refill.

The float ball valves are suitable for both clean and DW bowser.